

TAFFIO® GQT-T3 - Series

Model 3&Y AMD Ryzen Installation Steps



Step 1 Disassemble the Dashboard Decoration Cover in left Side
Step 2 Disassemble the Dashboard Decoration Cover in Right Side
Step 3 Remove the Dashboard Cover slightly from one side to another side



Step 4 Pick up the Cover
Step 5 Insert the Cables from the T3 into the 37th Hole on the Cover
Step 6 From left to right count 37 Holes and Insert the 2 Cable from T3 into the Holes



Step 7 Put the T3 in to the Board with right position
Step 8 Install the fix Screw in back side of the Cover
Step 9 Remove the Buckles from the Glove Box



Step 10 Remove the front right seat A-pillar baffle
Step 11 Original car blue protocol interface A
Step 12 Original car white power interface B



Step 13 Remove the power port C of the original vehicle
Step 14 Schematic diagram of power cable interface
Step 15 Power cable A1 is plugged into the original car A interface



Step 16 Power cable B1 interface pair plug original car B
Step 17 Power Cable C1 is paired with the original car C
Step 18 Routing the Cable according to the position shown



Step 19 Use Tape to fix the cable
Step 20 Connect the Cables with the T3
Step 21 Put back the Cover on Dashboard



Step 22 Installation is Complete

Installation Precautions:

When installing, it needs to be powered off and all functions are tested before loading

TAFFIO® GQT-T3 - Series

Model 3&Y Intel Installation Steps



Step 1 Disassemble the Dashboard Decoration Cover in left Side
Step 2 Disassemble the Dashboard Decoration Cover in Right Side
Step 3 Remove the Dashboard Cover slightly from one side to another side



Step 4 Pick up the Cover
Step 5 Insert the Cables from the T3 into the 37th Hole on the Cover
Step 6 From left to right count 37 Holes and Insert the 2 Cable from T3 into the Holes



Step 7 Put the T3 in to the Board with right position
Step 8 Install the fix Steel in back side of the Cover
Step 9 Remove the Buckles from the Glove Box



Step 10 Remove the Glove Box Cover
Step 11 Pull off the Grey Color Plug
Step 12 Connect the Cable which T3 Provided with the Grey Color Plug



Step 13 Connect the Original Plug in the other side of the T3 Cable
Step 14 Routing the Cable according to the position shown
Step 15 Use Tape to fix the cable



Step 16 Connect the Cables with the T3
Step 17 Put back the cover on Dash
Step 18 Side Press Fit Effect



Installation Precautions:

When installing, it needs to be powered off and all functions are tested before loading

Step 19 Installation is Complete